



1. Excavate a suitable strip footing to support the Drainer units.



2. Drainer Outfalls and Rodding boxes should be installed first along with relevant pipe work to relevant soakaway or SuDs compliant system.



3. Before installing the Drainer units, apply a 5mm bead of M-Flex or paste M-Fix compound from the top of the aperture.



4. Lay the units onto a freshly mixed workable bedding concrete making sure you achieve a tight connection between each unit.



5. Haunch the units using bedding concrete of an appropriate thickness and depth.



6. Lay the paving flush with the top of the Drainer units. Accessories are available, please ensure you read through the full Drainer installation and maintenance guide.